



INSTALLATION INSTRUCTIONS

1. Locate and remove the 1/4" pipe plug from the 4th gear pressure port. (As shown in photos: fig.1 - 700R4, fig.2 - 200 4R)
2. Install the oil pressure switch provided with this kit into the pressure port (using the brass bushing as needed). Use a good quality Teflon sealant to prevent leaks (A 90 degree adapter may be used as well, but is not supplied).
3. Plug the white 4-way weatherpak connector from the harness assembly that is supplied with this kit into the mating connector located on the driver's side of the transmission.
4. Plug the single black connector on the red wire (at the opposite end of the harness assembly from the 4-way weatherpak connector) onto either of the two blade terminals on the oil pressure switch from #2 above.
5. Plug the single black connector from the other red wire assembly onto the opposite blade on the oil pressure switch, then take the loose end of this red wire, route it to the inside of your vehicle, and connect it thru the supplied 20 amp fuse kit to a "keyed-on" 12 volt ignition source (be sure to check your voltage source and make sure that it is only hot in the "keyed-on" position).
5. Attach the black wire from the 4-way weatherpak connector to a good chassis ground.



**American
Autowire**

www.americanautowire.com 856-933-0801

**TORQUE CONVERTER
LOCKUP HARNESS**

500412

92966169 REV 1.0 8/28/2012