

Calibration instructions for the PROFORM® Wired Vehicle Scale, part no. 67650.



LCD Display version 2.0 is shown. **(Use version 1.0 calibration instructions if your LCD Display looks different than shown)**

Legend:

FL = Front Left

FR = Front Right

RL = Rear Left

RR = Rear Right



PLEASE NOTE: A 550 lb (250 kg) weight is required. Any other weight can lead to permanent damage of the scale.

Procedure:

1. Connect the four weighing pads in the following order: FL, FR, RL, and then RR.
2. To turn on the system and enter calibration mode, press and hold the **TARE** and **Kg/lb** buttons, then while holding the two buttons down press and hold the **ON/OFF** button until "0000" appears at the upper left position of the LCD display. Release all three buttons once this is achieved. **Note: Scale pads are to be calibrated in the order described in the steps below.**
3. Put 550 lbs. on the FL pad, wait 10 seconds for it to stabilize.
4. Press and release the **Kg/lb** button, the FL area of the display should read "1111". This means the FL pad recorded the 550 pounds, and calibration of the FL pad is complete.
5. Put 550 lbs. on the FR pad, wait 10 seconds for it to stabilize.
6. Press and release the **Kg/lb** button, the FL area of the display should read "2222". This means the FR pad recorded the 550 pounds, and calibration of the FR pad is complete.
7. Put 550 lbs. on the RL pad, wait 10 seconds for it to stabilize.
8. Press and release the **Kg/lb** button, the FL area of the display should read "3333". This means the RL pad recorded the 550 pounds, and calibration of the RL pad is complete.
9. Put 550 lbs. on the RR pad, wait 10 seconds for it to stabilize.
10. Press and release the **Kg/lb** button, the FL area of the display should read "4444". This means the RR pad recorded the 550 pounds, and calibration of the RR pad is complete.
11. Power off by pressing the **ON/OFF** button.
12. Power unit on again, and check each pad to ensure it weighs a known weight correctly (i.e. get on the scale and weigh yourself).

For additional Tech Support, call (586)774-2500 or email tech@proformparts.com

©2013 Specialty Auto Parts U.S.A., Inc. All rights reserved.